

Satisloh


Machine serial number location

- 1- The identification plate on each machine has a variety of information on it including electrical requirements, weight, Satisloh part number, and machine serial number.
- 2- The machine serial number is referred to as either "Fabr. No." or "F. Nr." on the identification plate.
- 3- All of the following pictures were taken from the front of the machines except for the Toro-X-2S/SL.

AutoBlocker-S

Identification plate position: Lower left side, under conveyor, on electrical cabinet door.

Photo taken from: Front of machine.



PLA/PRA

Identification plate position: Lower right side, above air filter on electrical cabinet.

Photo taken from: Front of machine.



V50/V75

Identification plate position: Upper right side, towards rear, on machine cover.

Photo taken from: Front of machine.



VPro

Identification plate position: Upper left side, towards rear, on machine cover.

Photo taken from: Front of machine.



VFT-Compact

Identification plate position: Upper left side, towards rear, on side cover.

Photo taken from: Front of machine.



VFT-Ultra

Identification plate position: Upper left side, towards front, on front cover.

Photo taken from: Front of machine.



Toro-X-2S/SL

Identification plate position: Lower left side, on electrical cabinet door.

Photo taken from: **Back** of machine.



iFLEX

Identification plate position: Upper left side, towards rear.

Photo taken from: Front of machine.



AutoFLEX

Identification plate position: Upper right side, towards rear.

Photo taken from: Front of machine.



ES3

Identification plate position: Upper right side, towards rear.

Photo taken from: Front of machine.

