

ART-Deblocker-2

FULLY AUTOMATED LENS SURFACE DEBLOCKING





Lens waterjet deblocking



Block-nieces sorted back in job tray after deblocking



Designed for easier maintenance and serviceability

ART-DEBLOCKER-2

The next generation of fully automated ART deblocking technology, separates lens, block-piece, and adhesive using high-pressure water jet, enabling labs to fully automate their surfacing operation.

FEATURES + BENEFITS

- All in one automated ART lens waterjet deblocking system, cleans and removes glue remnants from lens and block-piece
- · Accurately sorts blocks back in job tray after deblocking
- Reduces water usage by up to 80% with new, external water filtration system WFS-2 (required)
- Needs up to 18% less floor space than its predecessor
- Highest level of robustness
- Side and back door can be fully opened for best maintenance and serviceability
- MES-360 Lite included, provides daily reports using preestablished KPI to track machine utilization, production throughput, and top five errors. Upgrade to full MES-360 system as lab needs grow.

OPTIONS

• Paperless tickets (RFID reader)

TECHNICAL SPECIFICATIONS

Productivity	~ 200 lenses/hour
	200 letises/floui
Working Range	lens diameter: 50-85mm lens thickness: up to 30mm plano up to +18 dpt base curve prism up to 5.5°, progressives, multi-focals, single vision lenses
Energy requirements	208 V / 63kVA or 400 V / 32 kVA, 50/60 Hz, 3 phases
Dimensions (wxdxh)	1502 x 2140 x 2078 mm* 60 x 85 x 82 inch*
Weight	about 1,900 kg / 4,190 lb
Communication	TCP/IP or RS232

without water-filtration system and chiller



All technical data subject to change without notice. Verify details with Satisloh

CONTACT

Satisloh AG Neuhofstrasse 12 CH- 6340 Baar Switzerland Phone: +41 (0) 41766 16 16 Email: info@satisloh.com

www.satisloh.com

North America

Central & South

Phone: Email: Europe Asia

info.usa@satisloh.com +49 (0) 6441 912 0 Phone: info.de@satisloh.com +852 27 56 7711 Phone: info.asia@satisloh.com +55 11 2930 8600 Phone: info.latam@satisloh.com

Sales +1 262 255 6001

Service +1 262 255 6001 service.usa@satisloh.com +49 (0) 6441 912 222 service.de@satisloh.com +852 27 56 7654 service.asia@satisloh.com +55 11 2930 8600 service.latam@satisloh.com

