






Automated, fast and precise lens loadina



UV-cured adhesive protects lens front side eliminatina tapina



Fast UV-curing process eliminates coolina time after blockina

ART-BLOCKER-A

ART-Blocker-A is a fully automated alloy-free blocking using Satisloh Spatial lens blocking technology. ART blocking eliminates hazardous substances protecting both environment and staff.

FEATURES + BENEFITS

- Automatically blocks lens blank and block-piece with a UV-curable adhesive.
- Machinable block-piece offers the best stability and lens support for round, oval, knife edge, high plus or other complex shapes
- Multiple block-piece diameters and curves for best lens support and lowest adhesive use.
- No manual handling required and front-side protection for improved yield.
- Automated imaging and probing included
- Front side probing reduces breakage and enables recalculation of back curve for most accurate optical power
- No tape required and no cooling time after blocking
- Supports universal, reusable block-pieces compatible with traditional production lines.
- Satisloh Spatial Blocking System eliminates prism rings
- Video recognition system ensures highest blocking ac-
- QR-code identifies each individual block-piece for selection, sorting, and re-use
- MES-360 Lite included, provides daily reports using preestablished KPI to track machine utilization, production throughput, and top five errors. Upgrade to full MES-360 system as lab needs grow.

TECHNICAL SPECIFICATIONS

Productivity	Up to 100 lenses/hour
Working Range	Blank diameter 58 – 85 mm
	Blank thickness up to 30 mm
	Plano up to +15 dpt. base curve
	Prism up to 5°
	Progressives, multi-focals, single vision
	lenses
Lens Materials	All standard organic materials, photo-
	chromic and polarized blanks
Dimensions	1215 x 1236 x 1907 mm /
(wxdxh)	48 x 49 x 75 in, without chiller
Weight	880 kg / 1940 lb





All technical data subject to change without notice. Verify details with Satisloh.

CONTACT

Satisloh AG Neuhofstrasse 12 CH- 6340 Baar Switzerland Phone: +41 (0) 41766 16 16 Email: info@satisloh.com

www.satisloh.com

North America

Central & South

Europe

Phone: Email: Phone: Email: Phone: Phone:

Email:

+1 262 255 6001 info.usa@satisloh.com +49 (0) 6441 912 0 info.de@satisloh.com +852 27 56 7711 info.asia@satisloh.com +55 (11) 2930 8600

Service +1 262 255 6001 service.usa@satisloh.com +49 (0) 6441 912 222 service.de@satisloh.com +852 27 56 7654 service.asia@satisloh.com +55 (11) 2930 8600 (pt) service.latam@satisloh.com

