



WHEN COMPETITIVENESS COUNTS

PRODUCTION CAPACITY

- Cycle time: ~ 5 → 6 minutes
- Lenses / cycle 6 → 8
- Lenses / hour 60 -> 80
- Type of lenses all types Ø 40 to 80 mm



5

Ų.

HARD COAT

TINTING

CONSUMABLES



SPECIFICATIONS

- Limited foot print
- 1 single zone for cleaning and hard coating
- Simple design for 1 or 2 shift use
- Remote connection to SCL service team
- Optimized water and energy consumption
- User friendly HMI

TECHNICAL DATA

Machine splittable in 2 parts for shipment Dimensions 360 x 137 x 208 cm Weight..... ~ 750 kg Electricity: ~ 5,9 kW / 400 V (3Ph + N + Gnd) Compressed air.....: No Flow machine left to right or from right to left CE and UL compliance

PERIPHERALS

- Chillers to maintain the coating temperature $+5 \rightarrow +20^{\circ}C$
- Curring ovens : stand alone or in-line
- Automatic osmosis unit for ultra pure water production
- Draining tank with lift pump
- Ultrasonic stripping for lenses and racks :
- stand alone or automatic cleaning machine
- A/C unit for coating zone
- Ergonomic preparation/control station
- Lens-holders and rack for 6 or 8 lenses

BENEFITS

- → For compact layout
- → ISO6 coating chamber
- Automatic detergent, alcohol and varnish refilling \rightarrow Easy maintenance, stable process and no production stop
 - \rightarrow Easy maintenance
 - → Easier and faster diagnosis. Upgrading possibility
 - → Sustainable process



