HARD COAT CLEANING TINTING PERIPHERALS CONSUMABLES EXPERTISE





HARD COATING AT ITS BEST

■ PRODUCTION CAPACITY

- Cycle time ~ 5 → 6 minutes
- Lenses / cycle 14 → 16
- Lenses / hour 140 → 192
- \bullet Type of lenses all types Ø 40 to 80 mm















HARD COAT CLEANING TINTING PERIPHERALS CONSUMABLES EXPERTISE



SPECIFICATIONS

- 1 single zone for cleaning and hard coating
- 2 axis robot with fixed horizontal beam for handling racks
- 1 IN and 1 OUT automatic conveyors
- Automatic detergent, alcohol and varnish refilling
- Customisable machines
- Designed for heavy-duty use
- Remote connection to SCL service team
- Optimized water and energy consumption
- User friendly HMI

BENEFITS

- → ISO6 coating chamber
- → Greater throughput due to shorter cycle time. Minimized vibration level
- → Less contamination of process zones. IN and OUT buffers
- → Easy maintenance, stable process and no production stop
- → Available options to fit customer's needs
- → Very limited downtime
- > Easier and faster diagnosis. Upgrading possibility
- → Sustainable process

TECHNICAL DATA

Weight..... ~ 1450 kg

Compressed air....: No

Flow machine left to right or from right to left

CE and UL compliance

PERIPHERALS

- Chillers to maintain the coating temperature +5 → +20°C
- Curring ovens : stand alone or in-line
- Automatic osmosis unit for ultra pure water production
- · Draining tank with lift pump
- Ultrasonic stripping for lenses and racks: stand alone or automatic cleaning machine
- A/C unit for coating zone
- Ergonomic preparation/control station
- Lens-holders and rack for 14 or 16 lenses



www.scl-intl.com



