





Tool storage area with lifetime and selection indicators



Barcode reader with eraonomic support



Easy to operate control system



Lens washing compartment with water jet and compressed air gun

TORO-FLEX

A manually operated lens polishers, designed to polish two lenses simultaneously. This technology considerably reduces the costs of production, eliminating activities related to the handling and storage of tools and materials. Additionally flexible polishing tools bring versatility and automation to the process. Toro-FLEX lens polisher can process surfaces of all geometries, and lenses of all organic materials.

FEATURES + BENEFITS

- Robust dual lens polisher, designed for easy operation.
- Polishes concave, spherical, toric, free-form lens surfaces, and all organic materials.
- Tangential kinematics during the polishing process ensuring short polishing times and optimized lens quality.
- Long-lasting flexible polishing tools ensure high lens accuracy and an attractive cost/lens ratio.
- Seven different types of flexible tools cover the entire working range of Rx lenses.
- Lens washing basin, water spray and air gun prevent polishing slurry from drying on lenses.
- Integrated tool storage area with LED lights that show wear and selection, ensuring suitable choice for high process stability.
- The perfect complement to Satisloh's VFT-macro generators.

TECHNICAL SPECIFICATIONS

Productivity	Up to 50 lenses / hour
Working range	Base curve concave: 0-14 dpt. Cylinder: 0-6 dpt. Lens diameter: 48-85 mm
Lens Material	All organic materials
Dimensions (wxdxh)	695 x 1344 x 1843 mm 27 x 53 x 73 in.
Weight	327 kg/ 720 lb



All technical data subject to change without notice. Verify details with Satisloh.

CONTACT

Satisloh AG Neuhofstrasse 12 CH- 6340 Baar Switzerland Phone: +41 (0) 41766 16 16 Fax: +41 (0) 41766 16 10

Email: info@satisloh.com Central & South www.satisloh.com

North America Phone: Email: Europe Phone: Phone:

Phone:

+1 262 255 6001 info.usa@satisloh.com +49 (0) 6441 912 0 info.de@satisloh.com +852 27 56 7711 info.asia@satisloh.com +55 (11) 2930 8600 info.latam@satisloh.com

Service +1 262 255 6001 service.usa@satisloh.com +49 (0) 6441 912 222 service.de@satisloh.com +852 27 56 7654 service.asia@satisloh.com +55 (11) 2930 8600 service.latam@satisloh.com

