1500-PO

MASS PRODUCTION VACUUM BOX COATER




Optical Manufacturing Solutions.






User-friendly HMI software

Larger Meissner trap



Ringless dome with 9 rows



Hydrophobic and oleophobic top coatings available

FEATURES + BENEFITS

Flexibility

- Valuable process flexibility: multitude of thin-film coating types on plastic, glass, and IR optics via physical vapor deposition (PVD)
- High-temperature (up to 300° C) or midrange temperature (up to 150° C) substrate heater options
- Standard dual crystal heads with shutter, . or optional twelve crystal indexer
- High material capacity EBG with IAD and thermal resistive sources, optional high output ion source

Efficiency

- Rapid production cycles for unpreceden-٠ ted throughput
- Large Meissner trap with exceptional surface area allows for rapid pump down times and therefore higher productivity
- Powerful and high pumping speed diffusion pump at 30,000 l/s
- Energy saving kit available

OPTIONS + ACCESSORIES

- Ringless full dome with up to 9 rows
- Segmented (six sector) dome
- Ultra-sonic cleaning systems
- Coating processes and consumables

Reliability

- Built for continuous operation and consistent high-quality coating results
- New simplified e-beam emitter with 50% fewer parts for increased reliability
- Stabilized process conditions with exceptional repeatability thanks to reduced pump times

Ease of use

- Full compatibility with Satisloh's MES-360 (Manufacturing Execution System)
- Intelligent, user-friendly HMI software and touchscreen for quick and easy process setup and adjustments
- Quick-change chamber shielding to minimize maintenance time

TECHNICAL SPECIFICATIONS

| Capacity | Up to 317 lenses at Ø 70 mm |
|---------------------|-------------------------------|
| Substrate materials | Plastic, glass, and IR optics |
| Dimensions (wxdxh) | 2384 x 3295 x 2765 mm |
| | 94 x 130 x 109 inches |
| Weight | 3900 kg / 8598 lb |

All technical data subject to change without notice. Verify details with Satisloh.

CONTACT

| Satisloh AG | |
|----------------------------|-----------------|
| Neuhofstrasse 12 | North America |
| CH- 6340 Baar | |
| Switzerland | Europe |
| Phone: +41 (0) 41766 16 16 | |
| Fax: +41 (0) 41766 16 10 | Asia |
| Email: info@satisloh.com | |
| | Central & South |
| www.caticlob.com | America |

info.usa@satisloh.com +49 (0) 6441 912 0 Email: Phone: Email: info.de@satisloh.com +852 27 56 7711 info.asia@satisloh.com Phone: mail: Phone: +55 (11) 2930 8600 Email: info.latam@satisloh.com

Phone:

America

Sales +1 262 255 6001 Service +1 262 255 6001 precision@satislohusa.com +39 02 33 55 66 77 service.it@satisloh.com +852 27 56 7654 service.asia@satisloh.com +55 (11) 2930 8600 (pt) +57 300 798 3374 (es) precision@satislohusa.com

-2

satisloh®

www.satisloh.com